

 <p data-bbox="706 598 998 777">Press these buttons to increase and decrease the volume. Press MUTE to mute outgoing audio.</p>	<p data-bbox="1055 210 1383 483">To increase the audio VOLUME in the ITV classroom, press the button next to the up arrow.</p> <p data-bbox="1055 525 1383 756">To decrease the audio VOLUME, press the button next to the down arrow.</p> <p data-bbox="1055 798 1383 1323">The MUTE button will mute the audio broadcast to the other sites. Unless the button is pressed at the other site or sites, you will continue to hear audio transmitted from the other locations.</p>
--	--

TIP: Increase or decrease the volume on the television sets within the room to compensate for low or loud audio. Please note, feedback may occur if the television volume is set too loud.