




To disconnect a campus from the videoconference, press the **CALL STATUS CONTROL** button.



Next, touch the **DISCONNECT** icon.

Note: You may press **EXIT** at anytime to return to the home screen.



The screenshot shows a videoconference control interface. At the top, there is a status bar with the time '10:47', a 'VCR REC' indicator, and the date '08/15'. Below this is a 'Message Window'. The main area displays a list of participants: 'CLIFTON' and 'LAWRENCEBUR'. Next to each name is a 'DISC' button. A white text box with a black border is overlaid on the 'DISC 1' button, containing the text: 'Touch the DISC icon next to the campus you are disconnecting.' To the right of the participant list are two large buttons: 'DISCONNECT' and 'CONNECT'. At the bottom right is an 'EXIT' button. At the bottom left, there is a small instruction: 'Press and hold 'Disconnect' to end conference'. On the far right edge of the screen, there are several physical buttons labeled 'MUTE', 'CALL', 'MUTE', and 'END'.

Then, touch the **DISC** icon that is next to the name of the campus you are disconnecting from the videoconference.

Repeat steps until all campuses are disconnected.

Note: You may press **Cancel** and then **EXIT** at anytime to return to the home screen.